



# RJ45 TERMINATION

Provided by [DRS Systems](http://www.drs-systems.com)

<u>568B</u>	<u>568A</u>
	
<p><u>Left to Right:</u></p> <ul style="list-style-type: none"><li>Orange Stripe</li><li>Orange</li><li>Green Stripe</li><li>Blue</li><li>Blue Stripe</li><li>Green</li><li>Brown Stripe</li><li>Brown</li></ul>	<p><u>Left to Right:</u></p> <ul style="list-style-type: none"><li>Green Stripe</li><li>Green</li><li>Orange Stripe</li><li>Blue</li><li>Blue Stripe</li><li>Orange</li><li>Brown Stripe</li><li>Brown</li></ul>

Crossover cables are configured with 1-568B on 1 end and 1-568A on the other.

Information provided as is through: <http://www.dfw-networksupport.com/>